


## POWER ON

Press the power key  until beep is heard.

## POWER OFF


Tap the power key briefly, the message below will display. Press [ENTER] to continue.



## STATUS BAR



## TOGGLE

Press  and then [F1] or [F2] to toggle to a populated application slot. Status bar will reflect the slot in the right corner.



## FORMATTING LETTERS

Press the number with the corresponding letter until the number changes to the correct letter.

Letters must be changed within a ½ second.










Example:

To form **J**, press [5] 2 times

To form **K**, press [5] 3 times

To form **j**, press [5] 5 times

## PHYSICAL KEYPAD

	Press the red key to cancel the current operation or return to the previous menu.
	Press the yellow key to clear an action or backspace clearing each character.
	Press the green key to signify to the terminal that the task is complete, or press to enable a function or perform an action based on inputted data.
	Press the feed key to advance the receipt.
	Press up arrow to return to the previous screen or move up in sub-menus or moves to far right of text. Use with power key to toggle slots.
	Press the down arrow to move to the next screen or move down sub-menus or moves far left of text. Use with power key to toggle slots.
	Press the F1 key move the cursor left in text boxes. Used along with power button switches populated slots.
	Press the F2 key move the cursor left in text boxes. Used along with power button switches populated slots.
	Press power briefly and then ENTER to turn on. Used with the F1 or F2 switches populated slots.

## KEY FUNCTIONS

Use up arrow [↑] key and down arrow [↓] key to highlight a menu item.

Press [ENTER] to select the currently highlighted menu item.

Press the number key corresponding to the menu item.

To exit out of a sub-menu, press [CANCEL].

## **24 X 7 TECHNICAL SUPPORT**

866.392.8326 (option 4)

Email: support@exadigm.com

The terminal model and serial number will be confirmed by rep.