

World Headquarters/ North America:

Hypercom Corporation
2851 W. Kathleen Road, Phoenix, Arizona 85053, USA • Tel: +1.602.504.5000 • Fax: +1.602.504.4655

HYC Latin America:

Hypercom Industria e Comercio LTDA
Centro Empresarial Atibaia
Rodovia Dom Pedro 1, KM 07, 5 Av.
Tegula, 888-Ponte Alta
Atibaia 12940-000, Brazil

Tel: +55.11.4417.7000
Fax: +55.11.4417.7060

HYC EMEA:

Hypercom EMEA
Unit 2, Woking Eight
Forsyth Road
Woking, GU21 5SB,
United Kingdom

Tel: +44.1483.718600
Fax: +44.1483.718601

HYC Asia:

Hypercom Asia
21/F Metro Centre II
21 Lam Hing Street
Kowloon Bay, Kowloon
Hong Kong

Tel: +85.2.2561.6800
Fax: +85.2.2561.5890

HYC Australia:

Hypercom Australia
Unit 1,
11 Orion Road
Lane Cove, NSW 2066
Australia

Tel: +612.9420.6444
Fax: +612.9420.6466

©2005-2006 Hypercom Corporation, all rights reserved. Hypercom is a registered trademark of Hypercom Corporation. Hypercom logo and Optimum designs are trademarks of Hypercom Corporation. All other products or services mentioned in this document are trademarks, service marks, registered trademarks or registered service marks of their respective owners.

Hypercom Corporation is one of the largest global providers of complete electronic payment solutions and value-added services at the point-of-transaction. It is the only company in its industry to provide complete, end-to-end high security payment solutions, from countertop and mobile credit/debit payment terminals to the network devices and services that quickly expedite the fast and secure transmission of vital financial and business data.

Hypercom markets its products and services through a worldwide network of sales, service and development offices. Regional sales headquarters are located in Brazil, China, Hungary, Mexico and the United Kingdom.

COMPLIANCE*:

- FCC Part 15 (ICES-003)
- UL/cUL Listed (UL 60950-1)
- EN55022
- EN55024
- EN60950-1
- AS/NZS CISPR 22
- AS/NZS 60950-1
- CISPR 22
- IEC 60950-1 (CB Scheme)

*Includes D1100 Docking Station Charger
Bluetooth models utilize Ezurio blu 2i Transceiver

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. The user is cautioned that changes or modifications not expressly approved by Hypercom could void the user's authority to operate the equipment.

940472-001, Rev. B

04/06



www.hypercom.com

Terminal Installation Guide



www.hypercom.com



Optimum M2100 Installation Guide

Equipment Check List →

WARNING:

- The battery pack is a Li-ion polymer battery which can explode if not properly replaced, handled or disposed of. Dispose of the battery in accordance with local regulations. Use only batteries recommended by Hypercom as a replacement.
- Recharge only with approved chargers designed for this product.
- Do not use if visibly damaged.
- Do not expose to temperatures above 140 °F or 60 °C.
- Do not disassemble.
- Do not short circuit battery pack terminals.
- Do not incinerate or crush.
- Keep out of reach of children and pets.
- Dispose of properly.

A1



Optimum M2100

B1



Paper Roll

The Optimum M2100 terminal comes pre-loaded with a Li-ion Battery Pack (DC 7.4V 2200mAh). A fully charged battery can complete more than 300 transactions before requiring another charge. NOTE: Charge the battery for 4-6 hours before initial use of the terminal.


To recharge the terminal, use the Hypercom D1100 or D2100 Docking Station (in separate box).

To program the terminal while on the docking station, ensure that the terminal is fully charged.

For additional information, visit our website at www.hypercom.com.

Powering the Terminal

A1




Power Switch


Paper Roll Installation



Lift and open paper cover



Drop paper roll into paper holder



Close paper cover